



Micro-Metrics Company

4450 Ansley Lane
CUMMING, GA 30040-5252
www.micro-metrics.com

M-M Voice: 678-947-3723
M-M FAX: 678-807-2867
Elenor2011@Micro-Metrics.com

Replacing the bulb in the OG202 and OG204 Tooke Paint Inspection Gauge

Replacing the bulb in an OG200 gauge requires removing (by unscrewing) the old bulb from the gauge, and screwing in a new bulb. (Micro-Metrics now offers a longer-lasting, more rugged LED bulb for these gauges.)



Step 1.

The bulb is mounted in the body of the gauge, and uses a standard lightbulb screw mount.

Step 2.

Gently grasp the glass portion of the bulb and rotate the bulb toward the left (anti-clockwise) to remove.



Step 3.

Gentle grasp the glass portion of the new bulb and rotate ("screw-in") the bulb towards the right to secure. Do not over-tighten the bulb as this may force the lamp-battery contact out of position.

